

UNDERHOOD MAINTENANCE COMPONENT LOCATIONS—5.0L ENGINE

- | | | |
|---|---|------------------------------------|
| 1. Battery | 6. PCV valve | 11. Air cleaner assembly |
| 2. Spark plugs (4 on each side of the engine) | 7. Spark plug wires | 12. Power steering fluid reservoir |
| 3. Drive belt | 8. Distributor cap and rotor (under dust cover) | 13. Coolant recovery tank |
| 4. Engine oil fill cap | 9. Engine oil dipstick | 14. Radiator cap |
| 5. Automatic transmission oil dipstick | 10. Brake master cylinder reservoir | |

