

SERVICE CODE (COMPONENT)	PINPOINT TEST STEP
11 (ABS Module)	AA1
17 (Reference Voltage)	BB1
18 (Isolation Valve No. 1)	BB18
19 (Isolation Valve No. 2)	BB20
22 (LH Front Inlet Valve) or reference voltage (ABS only)	BB1
23 (LH Front Outlet Valve)	BB4
24 (RH Front Inlet Valve)	BB6
25 (RH Front Outlet Valve)	BB8
26 (RH Rear Inlet Valve)	BB10
27 (RH Rear Outlet Valve)	BB12
28 (LH Rear Inlet Valve)	BB14
29 (LH Rear Outlet Valve)	BB16
31 (LH Front Sensor)	CC1
32 (RH Front Sensor)	CC8
33 (RH Rear Sensor)	CC15
34 (LH Rear Sensor)	CC22
35 (LH Front Sensor)	CC1
36 (RH Front Sensor)	CC8
37 (RH Rear Sensor)	CC15

SERVICE CODE (COMPONENT)	PINPOINT TEST STEP
38 (LH Rear Sensor)	CC22
41 (LH Front Sensor)	CC1
42 (RH Front Sensor)	CC8
43 (RH Rear Sensor)	CC15
44 (LH Rear Sensor)	CC22
51 (LH Front Outlet Valve)	DD1
52 (RH Front Outlet Valve)	DD5
53 (RH Rear Outlet Valve)	DD9
54 (LH Rear Outlet Valve)	DD13
55 (LH Front Sensor)	CC1
56 (RH Front Sensor)	CC8
57 (RH Rear Sensor)	CC15
58 (LH Rear Sensor)	CC22
61 (FLS Circuits)	EE1
62 (Travel Switch)	EE1
63 (Pump Motor Speed Sensor)	EE11
64 (Pump Motor Pressure)	EE32
66 (Pressure Switch)	EE1
67 (Pump Motor Relay)	E1
71 (LH Front Sensor)	CC1
72 (RH Front Sensor)	CC8
73 (RH Rear Sensor)	CC15
74 (LH Rear Sensor)	CC22
75 (LH Front Sensor)	CC1
76 (RH Front Sensor)	CC8
77 (RH Rear Sensor)	CC15
78 (LH Rear Sensor)	CC22