

Follow Maintenance Schedule B if, generally, you drive your vehicle on a daily basis for more than 16 km (10 miles) and NONE OF THE UNIQUE DRIVING CONDITIONS SHOWN IN SCHEDULE A APPLY TO YOUR DRIVING HABITS.

SERVICE INTERVALS Perform at the months or distances shown, whichever comes first.	Miles x 1000	7.5	15	22.5	30	37.5	45	52.5	60
	Kilometers x 1000	12	24	36	48	60	72	84	96
EMISSIONS CONTROL SERVICE									
Replace Engine Oil and Filter (Every 6 Months) OR 7,500 Miles Whichever Occurs First		X	X	X	X	X	X	X	X
Replace Spark Plugs					X				X
Replace Crankcase Emission Filter①					X				X
Inspect Accessory Drive Belt(s)					X				X
Replace Air Cleaner Filter①					X				X
Replace PCV Valve and Crankcase Emission Filter — 5.0L Engine			(X)		(X)		(X)		X
Check/Clean Choke Linkage (5.8L only)					X				X
Change Engine Coolant Every 36 Months OR					X				X
Check Engine Coolant Protection, Hoses and Clamps	ANNUALLY								
GENERAL MAINTENANCE									
Check Exhaust Heat Shields					X				X
Lube Suspension			X		X		X		X
Lubricate Steering Linkage			X		X		X		X
Inspect Disc Brake Pads and Rotors (Front)②					X				X
Inspect Brake Linings and Drums (Rear)②					X				X
Inspect and Repack Front Wheel Bearings					X				X
Rotate Tires		X		X		X		X	

① If operating in severe dust, more frequent intervals may be required.

② If your driving includes continuous stop-and-go driving or driving in mountainous areas, more frequent intervals may be required.

X All items designated by an X must be performed in all states.

(X) This item not required to be performed, however, Ford recommends that you also perform maintenance on items designated by an (X) in order to achieve best vehicle operation. Failure to perform this recommended maintenance will not invalidate the vehicle emissions warranty or manufacturer recall liability.