

Function	Trade number
<b>Exterior lights</b>	
Rear	
Tail lamp, stoplamp, turn lamp (sedan)	3157
Tail lamp, stoplamp, turn lamp (wagon)	1157
Side marker	194
Front	
Parklamp, turn lamp	3157
Side marker	916
Parklamp only	916
Backup lamp (sedan)	3156
Backup lamp (wagon)	1156
Cornering lamp	3156
License plate lamp (sedan)	194
License plate lamp (wagon)	168
High-mounted brakelamp (opt.)	912
Headlamps (hi and lo)	H4656
Headlamps (high beam)	H4651
<b>Interior lights</b>	
Luggage compartment lamp	912
Cargo lamp (wagon)	906
Dome lamp	561
Dome/map lamp (opt.)	
Dome	561
Map	105
Visor vanity lamp (opt.)	168
Engine compartment lamp (opt.)	912
<b>Instrument panel lights</b>	
Glove box	194
High beam indicator	194
I/P ashtray lamp	161
Radio illumination	•
Turn signal indicator	194
Warning lights (all)	194
“PRNⓈD1” bulb	194
Heater or heater — A/C	161
Parking brakelamp (opt.)	194
Rear window defroster lamp (opt.)	2162
Instrument illumination lamp	194

• Refer bulb replacement to a Ford authorized radio service center.