

# MANUFACTURER RECOMMENDED SEVERE MAINTENANCE INTERVALS

## VEHICLE MAINTENANCE INTERVAL

Miles (x1000)	3	6	9	12	15	18	21	24	27	30	33	36	39	42	45	48	51	54	57	60
km (x1000)	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100

Component	Type of Service																				
Engine oil and filter	Replace	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Tires	Rotate		✓		✓		✓		✓		✓		✓		✓		✓		✓		✓
Air cleaner	Replace									✓											✓
Spark plugs ①	Replace																				
Drive belt	Inspect																				✓
Cooling system	Inspect					✓				✓						✓					✓
Coolant	Replace																✓				
PCV valve	Replace																				✓
Automatic transmission fluid & filter	Replace						✓								✓						
Exhaust heat shields	Inspect									✓											✓
Brake linings and drums	Inspect			✓		✓			✓			✓			✓			✓			
Brake pads and rotors	Inspect			✓		✓			✓			✓			✓			✓			
Fuel filter (NGV Crown Victoria) ②	Replace							✓									✓				
Lubricate suspension	Inspect					✓				✓						✓					✓
Brake line hoses and connections	Inspect					✓				✓						✓					✓
Front suspension	Inspect					✓				✓						✓					✓
Bolts and nuts on chassis body	Inspect					✓				✓						✓					✓
Steering linkage operation	Inspect					✓				✓						✓					✓

Perform maintenance at the same intervals for mileage beyond that on this chart

Follow the severe service interval schedule if the vehicle is driven in the following conditions:

towing a trailer or using a car-top carrier

operating in severe dust conditions

extensive idling such as a police car, taxi, or delivery service

short trips of less than 10 miles when outside temperatures remain below 0°F (-18°C)

① Replace every 100,000 miles.

② Also drain coalescer