

# Troubleshooting the Cooling System

Problem	Cause	Solution
Coolant loss—boilover	<ul style="list-style-type: none"> <li>Faulty head gasket</li> <li>Cracked head, manifold, or block</li> <li>Faulty radiator cap</li> </ul>	<ul style="list-style-type: none"> <li>Replace head gasket</li> <li>Replace as necessary</li> <li>Replace cap</li> </ul>
Coolant entry into crankcase or cylinder(s)	<ul style="list-style-type: none"> <li>Faulty head gasket</li> <li>Crack in head, manifold or block</li> </ul>	<ul style="list-style-type: none"> <li>Replace head gasket</li> <li>Replace as necessary</li> </ul>
Coolant recovery system inoperative	<ul style="list-style-type: none"> <li>Coolant level low</li> <li>Leak in system</li> <li>Pressure cap not tight or seal missing, or leaking</li> <li>Pressure cap defective</li> <li>Overflow tube clogged or leaking</li> <li>Recovery bottle vent restricted</li> </ul>	<ul style="list-style-type: none"> <li>Replenish coolant to FULL mark</li> <li>Pressure test to isolate leak and repair as necessary</li> <li>Repair as necessary</li> <li>Replace cap</li> <li>Repair as necessary</li> <li>Remove restriction</li> </ul>
Noise	<ul style="list-style-type: none"> <li>Fan contacting shroud</li> <li>Loose water pump impeller</li> <li>Glazed fan belt</li> <li>Loose fan belt</li> <li>Rough surface on drive pulley</li> <li>Water pump bearing worn</li> <li>Belt alignment</li> </ul>	<ul style="list-style-type: none"> <li>Reposition shroud and inspect engine mounts (on electric fans inspect assembly)</li> <li>Replace pump</li> <li>Apply silicone or replace belt</li> <li>Adjust fan belt tension</li> <li>Replace pulley</li> <li>Remove belt to isolate. Replace pump.</li> <li>Check pulley alignment. Repair as necessary.</li> </ul>
No coolant flow through heater core	<ul style="list-style-type: none"> <li>Restricted return inlet in water pump</li> <li>Heater hose collapsed or restricted</li> <li>Restricted heater core</li> <li>Restricted outlet in thermostat housing</li> <li>Intake manifold bypass hole in cylinder head restricted</li> <li>Faulty heater control valve</li> <li>Intake manifold coolant passage restricted</li> </ul>	<ul style="list-style-type: none"> <li>Remove restriction</li> <li>Remove restriction or replace hose</li> <li>Remove restriction or replace core</li> <li>Remove flash or restriction</li> <li>Remove restriction</li> <li>Replace valve</li> <li>Remove restriction or replace intake manifold</li> </ul>

**NOTE:** Immediately after shutdown, the engine enters a condition known as heat soak. This is caused by the cooling system being inoperative while engine temperature is still high. If coolant temperature rises above boiling point, expansion and pressure may push some coolant out of the radiator overflow tube. If this does not occur frequently it is considered normal.