

# CRUISE CONTROL TROUBLESHOOTING

<i>Problem</i>	<i>Possible Cause</i>
Will not hold proper speed	Incorrect cable adjustment Binding throttle linkage Leaking vacuum servo diaphragm Leaking vacuum tank Faulty vacuum or vent valve Faulty stepper motor Faulty transducer Faulty speed sensor Faulty cruise control module
Cruise intermittently cuts out	Clutch or brake switch adjustment too tight Short or open in the cruise control circuit Faulty transducer Faulty cruise control module
Vehicle surges	Kinked speedometer cable or casing Binding throttle linkage Faulty speed sensor Faulty cruise control module
Cruise control inoperative	Blown fuse Short or open in the cruise control circuit Faulty brake or clutch switch Leaking vacuum circuit Faulty cruise control switch Faulty stepper motor Faulty transducer Faulty speed sensor Faulty cruise control module

Note: Use this chart as a guide. Not all systems will use the components listed.