

MANUFACTURER RECOMMENDED NORMAL MAINTENANCE INTERVALS

VEHICLE MAINTENANCE INTERVAL

		Miles (x1000)	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
		km (x1000)	8	16	24	32	40	48	56	64	72	80	88	96	104	112	121	128
Component	Type of Service																	
Engine oil and filter	Replace	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Tires	Rotate	✓		✓		✓		✓		✓		✓		✓		✓		
Air cleaner	Replace							✓						✓				
Spark plugs ①	Replace																	
Drive belt	Inspect													✓				
Cooling system	Inspect			✓				✓			✓			✓			✓	
Coolant	Replace											✓						✓
PCV valve	Replace													✓				
Automatic transmission fluid and filter	Replace							✓						✓				
Exhaust heat shields	Inspect							✓						✓				
Brake linings and drums	Inspect		✓		✓			✓		✓		✓		✓		✓		✓
Brake pads and rotors	Inspect		✓		✓			✓		✓		✓		✓		✓		✓
Fuel filter (NGV Crown Victoria) ②	Replace						✓					✓					✓	
Lubricate suspension	Inspect		✓		✓			✓		✓		✓		✓		✓		✓
Brake line hoses and connections	Inspect							✓						✓				
Front suspension	Inspect							✓						✓				
Bolts and nuts on chassis body	Inspect							✓						✓				
Steering linkage operation	Inspect							✓						✓				

Perform maintenance at the same intervals for mileage beyond that on this chart

Follow the normal service interval schedule if the vehicle is driven in the following conditions:

The vehicle is driven more than 10 miles on a daily basis

The vehicle is not used in the following conditions:

towing a trailer or using a car-top carrier

operating in severe dust conditions

extensive idling such as a police car, taxi, or delivery service

short trips of less than 10 miles when outside temperatures remain below 0°F (-18°C)

① Replace every 100,000 miles.

②Also drain coalescer