

UNDERHOOD MAINTENANCE COMPONENT LOCATIONS—4.6L ENGINE

- | | | |
|---|--|---------------------------------------|
| 1. Battery | 6. PCV valve | 11. Engine oil fill cap |
| 2. Engine compartment fuse box | 7. Coolant recovery tank | 12. Power steering fluid reservoir |
| 3. Drive belt | 8. Automatic transmission oil dipstick | 13. Air cleaner assembly |
| 4. Spark plug wires | 9. Brake master cylinder reservoir | 14. Windshield washer fluid reservoir |
| 5. Spark plugs (4 on each side of the engine) | 10. Engine oil dipstick | |

