


See Page SA-79





DIFFERENTIAL CARRIER INSPECTION

1. CHECK RUNOUT OF COMPANION FLANGE

Using a dial indicator, measure the vertical and lateral runout of the companion flange.


Maximum vertical runout:

0.10 mm (0.0039 in.)

Maximum lateral runout:

0.10 mm (0.0039 in.)

If the runout is greater than the maximum, replace the companion flange.




2. CHECK DRIVE PINION PRELOAD

Using a torque wrench, measure the drive pinion preload using the backlash of the drive pinion and ring gear.

Preload (at starting):

0.6–1.0 N·m (6–10 kgf·cm, 5.2–8.7 in.·lbf)



3. CHECK TOTAL PRELOAD


Using a torque wrench, measure the total preload.

Total preload (at starting):

In addition to drive pinion preload

.4–0.6 N·m (4–6 kgf·cm, 3.5–5.2 in.·lbf)


If necessary, disassemble and inspect the differential.




DIFFERENTIAL CARRIER DISASSEMBLY

1. REMOVE A.D.D. ACTUATOR


- Remove the 4 bolts.
- Using a hammer handle, remove the actuator.





2. REMOVE DIFFERENTIAL CARRIER COVER

Remove the 8 bolts and tap off the cover with a plastic-faced hammer.




3. CHECK SIDE GEAR BACKLASH

Measure the side gear backlash while holding one pinion gear toward the case.

Standard backlash:

0.05–0.20 mm (0.0020–0.0079 in.)


If the backlash is out of specification, install the correct thrust washers. (See page [SA-76](#))




4. REMOVE LH SIDE GEAR SHAFT WITH TUBE

(a) Remove the 4 torx bolts.

Torx socket E14 (Part No.09044-00010 or locally manufactured tool)




(b) Using a plastic-faced hammer, tap on the tube to remove it.




(c) Remove the sleeve.


(d) Remove the O-ring from the tube.

**5. REMOVE CLUTCH CASE**


- (a) Remove the 2 torx bolts.
Torx socket E14 (Part No.09044-00010 or locally manufactured tool)




- (b) Using a plastic-faced hammer, tap on the clutch case to remove it.

**6. REMOVE RH SIDE GEAR SHAFT**


Using SST, remove the side gear shaft.
SST 09910-00015 (09911-00011, 09912-00010, 09914-00011)

**7. REMOVE RH SIDE GEAR SHAFT OIL SEAL**

Using SST, remove the right side gear shaft oil seal.
SST 09308-00010

**8. REMOVE INTERMEDIATE SHAFT**

Using SST, pull off the intermediate shaft.
SST 09350-20015 (09369-20040), 09950-20017




9. CHECK RING GEAR RUNOUT

Using a dial indicator, measure the ring gear runout.

Maximum runout:

0.07 mm (0.0028 in.)

If the runout is greater than maximum, replace the ring gear and drive pinion as a set.



10. CHECK RING GEAR BACKLASH


- (a) Fix the dial indicator on the tooth surface at a 90° angle.
- (b) Holding the drive pinion flange, measure the ring gear backlash.

Ring gear backlash:

0.13–0.18 mm (0.0051–0.0071 in.)


If the backlash is not within specification, adjust the ring gear backlash.

HINT: Measure from 3 or more places on the circumference of the ring gear.




11. INSPECT TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION

(See page [SA-83](#))




12. REMOVE COMPANION FLANGE

- (a) Using a chisel and hammer, unstick the nut.




- (b) Using SST to hold the flange, remove the nut and plate washer.

SST 09330-00021




- (c) Using SST, remove the companion flange.
SST 09557-22022 (09557-22030)




13. REMOVE OIL SEAL AND OIL SLINGER

- (a) Using SST, remove the oil seal from the differential carrier.
SST 09308-10010
(b) Remove the oil slinger.




14. REMOVE REAR BEARING AND BEARING SPACER

- (a) Using SST, remove the rear bearing from the drive pinion.
SST 09556-30010
(b) Remove the bearing spacer.




15. REMOVE DIFFERENTIAL CASE ASSEMBLY

- (a) Place matchmarks on the bearing cap and differential carrier.
(b) Remove the 4 bolts and 2 bearing caps.




- (c) Using SST, remove the 2 side bearing plate washers.
SST 09504-22011
HINT: Measure the plate washer and note the thickness.



- (d) Remove the differential case with the bearing outer races from the differential carrier.
HINT: Tag the bearing outer races to show the location for reassembly.

16. REMOVE DRIVE PINION FROM DIFFERENTIAL CARRIER




17. REMOVE DRIVE PINION FRONT BEARING

Using SST and a press, remove the bearing from the drive pinion.


SST 09950-00020

HINT: If the drive pinion or ring gear are damaged replace them as a set.




18. REMOVE DRIVE PINION BEARING OUTER RACES

Using a brass bar and hammer, drive out the outer races from the differential carrier.




19. REMOVE RING GEAR


- (a) Place matchmarks on the ring gear and differential case.
(b) Using a screwdriver, unstake the lock plates.



- (c) Remove the 10 bolts and 5 lock plates.



- (d) Using a plastic-faced hammer, tap on the ring gear to separate it from the differential case.




20. REMOVE SIDE BEARINGS

Using SST, remove the side bearings from the differential case.


SST 09950-20017

HINT: Fix the claws of SST to the notch in the differential case.




21. DISASSEMBLE DIFFERENTIAL CASE ASSEMBLY

- (a) Using a pin punch and hammer, drive out the straight pin.




- (b) Remove the following parts:

- (1) Pinion shaft
- (2) Pinion gears
- (3) Pinion gear thrust washers
- (4) Side gears
- (5) Side gear thrust washers




- (c) Using a hammer and brass bar, drive out the needle bearings.



SIDE GEAR SHAFT INSPECTION AND REPLACEMENT


1. INSPECT CLUTCH HUB AND CLUTCH SLEEVE

- (a) Check the wear and damage of the clutch hub and clutch sleeve.
If necessary, replace them.
- (b) Check that clutch sleeve slides smoothly on the clutch hub.




2. REMOVE CLUTCH HUB

- (a) Using snap ring expander, remove the snap ring.
- (b) Remove the clutch hub from the side gear shaft.




3. REMOVE SIDE GEAR SHAFT FROM TUBE

- (a) Remove the 3 bearing retainer bolts.
- (b) Remove the side gear shaft from the tube.




4. REPLACE SIDE GEAR SHAFT BEARING


- (a) Using a snap ring expander, remove the snap ring.




- (b) Using SST and a press, remove the bearing.
SST 09950-00020



(c) Remove the bearing retainer.




(d) Using SST and a press, install the bearing.
SST 09316-60010 (09316-00040)




5. REPLACE SIDE OIL SEAL

(a) Using SST, remove the side oil seal.
SST 09308-00010



(b) With the oil seal lip facing upward, use press and plate to press in a new oil seal until its end is flush with the surface of the tube.




(c) Using SST, press in the oil seal.
SST 09554-14010


Press in depth:

2.5 mm (0.098 in.)


(d) Coat the lip of oil seal with MP grease.

**6. INSTALL SIDE GEAR SHAFT**


- (a) Install the side gear shaft into the tube.
 - (b) Torque the 3 bearing retainer bolts.
- Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)**

**7. INSTALL CLUTCH HUB**

- (a) Install the clutch hub to the shaft.



- (b) Using a snap ring expander, install the snap ring.



A.D.D. ACTUATOR INSPECTION AND REPLACEMENT


1. MEASURE CLEARANCE OF SLEEVE FORK AND CLUTCH SLEEVE

Using a feeler gauge, measure the clearance between the sleeve fork and clutch sleeve.

Maximum clearance:


0.35 mm (0.0138 in.)

If the clearance exceeds the limit, replace the fork or sleeve.




2. INSPECT A.D.D. ACTUATOR


- (a) Check that the sleeve fork moves to the actuator side when a vacuum of 500 mmHg (19.69 in.Hg, 66.7 kPa) is applied to port A. Also check that the vacuum remains constant. If not, replace the actuator.



- (b) Check that the sleeve fork moves away from the actuator when a vacuum of 500 mmHg (19.69 in.Hg, 66.7 kPa) is applied to port B. Also check that the vacuum remains constant. If not, replace the actuator.




3. REMOVE A.D.D. INDICATOR SWITCH




4. REMOVE SLEEVE FORK PIN

- (a) Using a hexagon wrench, remove the screw plug.




- (b) Using a hammer and punch, drive out the pin through the hole of clutch case cover.




5. SEPARATE ACTUATOR FROM CLUTCH CASE COVER AND REMOVE SLEEVE FORK

- (a) Remove the 2 bolts.




- (b) Separate the actuator from clutch case cover and remove the sleeve fork.
(c) Remove the O-ring from the actuator.




6. INSTALL SLEEVE FORK AND ACTUATOR INTO CLUTCH CASE COVER

- (a) Install a new O-ring to the actuator.
(b) Coat the O-ring with MP grease.
(c) Place the sleeve fork and install the actuator to the clutch case cover.




- (d) Torque the 2 bolts.
Torque: 21 N·m (210 kgf·cm, 15 ft·lbf)



7. INSTALL SLEEVE FORK PIN

- (a) Using a hammer and punch, drive in the pin through the hole of clutch case cover.




- (b) Coat the threads of screw plug with sealer.

Sealer:

Part No. 08826-00090, THREE BOND 1281 or equivalent

- (c) Using a hexagon wrench, install the screw plug.


Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)



8. INSTALL A.D.D. INDICATOR SWITCH

Install a new gasket and indicator switch.

Torque: 40 N·m (410 kgf·cm, 30 ft·lbf)





DIFFERENTIAL CARRIER ASSEMBLY

1. ASSEMBLY DIFFERENTIAL CASE

- (a) Using SST and a press, press in a new needle bearing.
NOTICE: Press in the bearings, with the engraved side of each bearing facing outward from the differential case.
 SST 09950-20017


Bearing press in depth:
2.0 mm (0.079 in.)




- (b) Install the proper thrust washers on the side gears.
 HINT: Using the table below, select thrust washers which will ensure that the backlash is within specifications.

Washer thickness:

Thickness mm (in.)	Thickness mm (in.)
0.96-1.04 (0.0378-0.0409)	1.16-1.24 (0.0457-0.0488)
1.06-1.14 (0.0417-0.0449)	1.26-1.34 (0.0496-0.0528)



- (c) Install the side gears, pinion gears, pinion gear thrust washers and pinion shaft in the differential case.
 HINT: Align the holes of the differential case and pinion shaft.




- (d) Measure the side gear backlash while holding one pinion gear toward the differential case.

Backlash:


0.05-0.20 mm (0.0020-0.0079 in.)

If the backlash is not within the specification, install side gear thrust washers with different thicknesses.




2. INSTALL STRAIGHT PIN AND STAKE DIFFERENTIAL CASE

- (a) Using a hammer and punch, install the straight pin through the differential case and hole of the pinion shaft.




- (b) Stake the differential case.



3. INSTALL RING GEAR ON DIFFERENTIAL CASE


- (a) Clean the contact surfaces of the differential case and ring gear.
 (b) Heat the ring gear to about 100°C (212°F) in boiling water.
 (c) Remove the ring gear from the boiling water.
 (d) After the moisture on the ring gear has completely evaporated, quickly install the ring gear to the differential case.

HINT: Align the matchmarks on the ring gear and the differential case.




- (e) Temporarily install 5 new lock plates and the 10 bolts so that the bolt holes in the ring gear and differential case are not misaligned.
 (f) After the ring gear has cooled sufficiently, torque the ring gear set bolts.

Torque: 97 N·m (985 kgf·cm, 71 ft·lbf)




- (g) Using a hammer and drift punch, stake the lock plates.
HINT: Stake one claw flush with the flat surface of the nut. For the claw contacting the protruding portion of the nut, stake only the half on the tightening side.



4. INSTALL SIDE BEARINGS

Using SST and a press, press the bearing into the differential case.

SST 09226-10010, 09950-20017



5. CHECK RING GEAR RUNOUT


(a) Install the differential case onto the carrier and install the plate washers to where there is no play in the bearing. (See page [SA-76](#))

(b) Install bearing caps. (See page [SA-82](#))

(c) Using a dial indicator, measure the runout of ring gear.

Maximum runout:

0.07 mm (0.0028 in.)



6. INSTALL DRIVE PINION FRONT AND REAR BEARING OUTER RACES


Using SST and a press, install new outer races.

Front:

SST 09608-35014 (09608-06020, 09608-06120)

Rear:

SST 09608-35014 (09608-06020, 09608-04110)




7. INSTALL DRIVE PINION FRONT BEARING

(a) Install the washer on the drive pinion.

HINT: First fit a washer with the same thickness as the washer which was removed, then after checking the tooth contact pattern, replace the washer with one of a different thickness if necessary.

(b) Using SST, press in the front bearing onto the drive pinion.


SST 09506-30012




8. TEMPORARILY ADJUST DRIVE PINION PRELOAD

(a) Install the drive pinion, rear bearing and oil slinger.


HINT: Assemble the spacer and oil seal after adjusting the gear contact pattern.




- (b) Using SST, install the companion flange.
SST 09557-22022 (09557-22030)
- (c) Coat the threads of the nut with MP grease.



- (d) Adjust the drive pinion preload by tightening the companion flange nut.
Using SST to hold the flange, tighten the nut.
SST 09330-00021
NOTICE: As there is no spacer, tighten the nut a little at a time, being careful not to overtighten it.




- (e) Using a torque wrench, measure the preload.
New bearing preload (at starting):
1.2-1.9 N·m (12-19 kgf·cm, 10.4-16.5 in.·lbf)
Reused bearing preload (at starting):
0.6-1.0 N·m (6-10 kgf·cm, 5.2-8.7 in.·lbf)




9. INSTALL DIFFERENTIAL CASE IN DIFFERENTIAL CARRIER

- (a) Place the bearing outer races on their respective bearings. Check that the left and right outer races are not interchanged.
- (b) Install the differential case in the differential carrier.




10. ADJUST RING GEAR BACKLASH

- (a) Install only the plate washer on the ring gear back side.
HINT: Ensure that the ring gear has backlash.




- (b) Snug down the washer and bearing by tapping on the ring gear with a plastic-faced hammer.




- (c) Hold the side bearing boss on the teeth surface of the ring gear and measure the backlash.

Backlash (reference):


0.13 mm (0.0051 in.)




- (d) Select a ring gear back side plate washer, using the backlash as reference. (See page [SA-81](#))




- (e) Select a ring gear teeth side plate washer with a thickness which eliminates any clearance between the outer race and case.




- (f) Remove the plate washers and differential case.
(g) Install the plate washer into the ring gear back side of the carrier.



- (h) Place the other plate washer onto the differential case together with the outer race, and install the differential case with the outer race into the carrier.




- (i) Using a plastic-faced hammer, snug down the washer and bearing by tapping the ring gear.



- (j) Using a dial indicator, measure the ring gear backlash.

Backlash:


0.13–0.18 mm (0.0051–0.0071 in.)



- (k) If not within specification, adjust by either increasing or decreasing the number of washers on both sides by an equal amount.


HINT: There should be no clearance between the plate washer and case.

Ensure that there is ring gear backlash.



11. ADJUST SIDE BEARING PRELOAD


- (a) Remove the ring gear teeth side plate washer and using a micrometer measure the thickness.



- (b) Using the backlash as a reference, install a new washer of 0.06–0.09 mm (0.0024–0.0035 in.) thicker than the washer removed.

HINT: Select a washer which can be pressed in 2/3 of the way with your finger.

- (c) Using a plastic-faced hammer, tap in the plate washer.




- (d) Recheck the ring gear backlash.

Backlash:

0.13–0.18 mm (0.0051–0.0071 in.)

- (e) If not within specification, adjust by either increasing or decreasing the washers on both sides by an equal amount.
HINT: The backlash will change about 0.02 mm (0.0008 in.) with 0.03 mm (0.0012 in.) alteration of the plate washer.




Washer thickness:

Thickness mm (in.)	Thickness mm (in.)
2.57–2.59 (0.1012–0.1020)	2.93–2.95 (0.1154–0.1161)
2.60–2.62 (0.1024–0.1031)	2.96–2.98 (0.1165–0.1173)
2.63–2.65 (0.1035–0.1043)	2.99–3.01 (0.1177–0.1185)
2.66–2.68 (0.1047–0.1055)	3.02–3.04 (0.1189–0.1197)
2.69–2.71 (0.1059–0.1067)	3.05–3.07 (0.1201–0.1209)
2.72–2.74 (0.1071–0.1079)	3.08–3.10 (0.1213–0.1220)
2.75–2.77 (0.1083–0.1091)	3.11–3.13 (0.1224–0.1232)
2.78–2.80 (0.1094–0.1102)	3.14–3.16 (0.1236–0.1244)
2.81–2.83 (0.1106–0.1114)	3.17–3.19 (0.1248–0.1256)
2.84–2.86 (0.1118–0.1126)	3.20–3.22 (0.1260–0.1268)
2.87–2.89 (0.1130–0.1138)	3.23–3.25 (0.1272–0.1280)
2.90–2.92 (0.1142–0.1150)	

12. INSTALL BEARING CAPS

Align the matchmarks on the cap and carrier.

Torque: 78 N·m (800 kgf·cm, 58 ft·lbf)




13. MEASURE TOTAL PRELOAD


Using a torque wrench, measure the total preload.

Total preload (at starting):

Add drive pinion preload



0.4–0.6 N·m (4–6 kgf·cm, 3.5–5.2 in·lbf)





14. INSPECT TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION


- Coat 3 or 4 teeth at 3 different positions on the ring gear with red lead.
- Hold the companion flange firmly and rotate the ring gear in both directions.
- Inspect the tooth pattern.




If the teeth are not contacting properly, use the following chart to select a proper washer for correction.

Washer thickness:


Thickness mm (in.)	Thickness mm (in.)
2.24 (0.0882)	2.51 (0.0988)
2.27 (0.0894)	2.54 (0.1000)
2.30 (0.0906)	2.57 (0.1012)
2.33 (0.0917)	2.60 (0.1024)
2.36 (0.0929)	2.63 (0.1035)
2.39 (0.0941)	2.66 (0.1047)
2.42 (0.0953)	2.69 (0.1059)
2.45 (0.0965)	2.72 (0.1071)
2.48 (0.0976)	

**15. INSTALL BEARING SPACER**


- (a) Remove the companion flange.
(See page SA-66)
- (b) Remove the oil slinger and rear bearing.
(See page SA-67)
- (c) Install a new bearing spacer.
- (d) Install the rear bearing and oil slinger.

**16. INSTALL OIL SEAL**


- (a) Using SST and a hammer, tap in a new oil seal.
SST 09554-30011
Oil seal drive in depth:
1.5 mm (0.059 in.)
- (b) Apply MP grease to the oil seal lip.

**17. INSTALL COMPANION FLANGE**

- (a) Using SST, install the companion flange.
SST 09557-22022 (09557-22030)



- (b) Install the plate washer.
- (c) Coat the threads of a new nut with MP grease and install it.
- (d) Using SST to hold the flange, tighten the nut.
SST 09330-00021
Torque: 120 N·m (1,225 kgf·cm, 89 ft·lbf)

**18. CHECK DRIVE PINION PRELOAD**


Using a torque wrench, measure the drive pinion preload using the backlash of the drive pinion and ring gear.

New bearing preload (at starting):

1.2-1.9 N·m (12-19 kgf·cm, 10.4-16.5 in·lbf)

Reused bearing preload (at starting):

0.6-1.0 N·m (6-10 kgf·cm, 5.2-8.7 in·lbf)




- If the preload is greater than the specification, replace the spacer.
- If the preload is less than the specification, retighten the nut 13 N•m (130 kgf•cm, 9 ft•lbf) at a time until the specified preload is reached.


Maximum torque:

223 N•m (2,275 kgf•cm, 165 ft•lbf)


If the maximum torque is exceeded while retightening the nut, replace the spacer and repeat the preload procedure. Do not back off the nut to reduce the preload.



19. RECHECK RING GEAR BACKLASH
(See page [SA-79](#))



20. RECHECK TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION
(See page [SA-83](#))




21. CHECK RUNOUT OF COMPANION FLANGE

Using a dial indicator, measure the vertical and lateral runout of the companion flange.


Maximum vertical runout:

0.10 mm (0.0039 in.)




Maximum lateral runout:
0.10 mm (0.0039 in.)

If the runout is greater than maximum, inspect the bearings.




22. STAKE DRIVE PINION NUT



23. INSTALL RH SIDE GEAR SHAFT OIL SEAL

- (a) Using SST and a hammer, tap in a new oil seal until its surface is flush with the differential carrier end.
 SST 09550-22011 (09550-00020, 09550-00031)
- (b) Apply MP grease to the oil seal lip.




24. INSTALL RH SIDE GEAR SHAFT

- (a) Install a new snap ring to the side gear shaft.
- (b) Using a plastic-faced hammer, tap in the side gear shaft to the differential case.

25. CHECK INSTALLATION OF SIDE GEAR SHAFT

- (a) Check that there is 2-3 mm (0.08-0.12 in.) of play in axial direction.
- (b) Check that the side gear shaft can not be pulled out by hand.




26. INSTALL INTERMEDIATE SHAFT

- (a) Install a new snap ring to the shaft.
- (b) Using a plastic-faced hammer, tap in the shaft to the differential case.


27. CHECK INSTALLATION OF INTERMEDIATE SHAFT

- (a) Check that there is 2-3 mm (0.08-0.12 in.) of play in axial direction.
- (b) Check that the intermediate shaft can not be pulled out by hand.




28. INSTALL CLUTCH CASE TO SIDE GEAR SHAFT TUBE


- (a) Install a new O-ring to the tube.
- (b) Coat the O-ring with MP grease.



- (c) Install the clutch case to the tube.
- (d) Torque the 2 torx bolts.
Torx socket E14 (Part No.09044-00010 or locally manufactured tool)
Torque: 78 N·m (800 kgf·cm, 58 ft·lbf)



29. INSTALL CLUTCH SLEEVE



30. INSTALL LH SIDE GEAR SHAFT TO DIFFERENTIAL CARRIER


- (a) Remove any old packing material and be careful not to drop oil on the contact surfaces of the differential carrier and clutch case.
- (b) Clean contacting surfaces of any residual packing material using gasoline or alcohol.
- (c) Apply seal packing to the carrier, as shown.


Seal packing:

Part No. 08826-00090, THREE BOND 1281 or equivalent

HINT: Install the side gear shaft within ten minutes after applying seal packing.

- (d) Install LH side gear shaft to the differential carrier.
- (e) Torque the 4 torx bolts.
Torx socket E14 (Part No.09044-00010 or locally manufactured tool)
Torque: 78 N·m (800 kgf·cm, 58 ft·lbf)





31. INSTALL DIFFERENTIAL CARRIER COVER

- Remove any old packing material and be careful not to drop oil on the contact surfaces of the differential carrier and carrier cover.
- Clean contacting surfaces of any residual packing material using gasoline or alcohol.
- Apply seal packing to the carrier cover, as shown.



Seal packing:

Part No. 08826-00090, THREE BOND 1281 or equivalent

HINT: Install the carrier cover within 10 minutes after applying seal packing.

- Install the differential carrier cover with the 8 bolts.

Torque: 47 N·m (475 kgf·cm, 34 ft·lbf)



32. INSTALL A.D.D. ACTUATOR

- Remove any old packing material and be careful not to drop oil on the contact surfaces of the actuator and clutch case.
- Clean contacting surfaces of any residual packing material using gasoline or alcohol.
- Apply seal packing to the clutch case, as shown.

Seal packing:

Part No. 08826-00090, THREE BOND 1281 or equivalent

HINT: Install the actuator within 10 minutes after applying seal packing.

- Torque the 4 bolts.

Torque: 21 N·m (210 kgf·cm, 15 ft·lbf)

