









STEERING COLUMN PREPARATION

SST (SPECIAL SERVICE TOOLS)

| | | |
|---|-----------------------------------|------------------------|
|  | 09609-20011 Steering Wheel Puller | |
|  | 09910-00015 Puller Set | (Tilt steering column) |
|  | (09911-00011) Puller Clamp | |
|  | (09912-00010) Puller Slide Hammer | |
|  | 09950-20017 Universal Puller | (Tilt steering column) |
|  | (09956-00010) Tightening Piece | |

RECOMMENDED TOOLS

| | | |
|---|--------------------------|---------------------------------------|
|  | 09904-00010 Expander Set | For removing and installing snap ring |
|  | (09904-00050) No. 4 Claw | |

EQUIPMENT

| | |
|---------------|--|
| Torque wrench | |
|---------------|--|