













PREPARATION**SST (SPECIAL SERVICE TOOLS)**

	09223-56010 Crankshaft Rear Oil Seal Replacer	Rear axle bearing removal
	09308-00010 Oil Seal Puller	Oil seal removal
	09515-30010 Rear Wheel Bearing Replacer	
	09521-25011 Rear Axle Shaft Puller	To remove and install the rear axle shaft from the backing plate
	09608-35014 Axle Hub & Drive Pinion Bearing Tool Set	
	(09608-06100) Front Hub Outer Bearing Replacer	Rear axle bearing removal
	(09608-06180) Drive Pinion Rear Bearing Cup Replacer	Rear axle bearing installation
	09608-30012 Front Hub & Drive Pinion Bearing Tool Set	Oil seal installation
	(09608-04020) Handle	
	(09608-04070) Front Hub Inner Bearing Cup Replacer	
	(09608-04100) Drive Pinion Front Bearing Cup Replacer	

RECOMMENDED TOOLS

	09905-00012 Snap Ring No. 1 Expander	
---	--------------------------------------	--

EQUIPMENT

Dial indicator	
Torque wrench	