



## SEAT BELT COMPONENTS

Separate Seat



Sprit Bench Seat and Bench Seat




BO3275  
BO3274

N·m (kgf·cm, ft·lbf) : Specified torque

**COMPONENTS (Cont'd)**


Extra Cab



B03277

**N·m (kgf·cm, ft·lbf)** : Specified torque

B03277



800632

## SEAT BELT INSPECTION


### Emergency Locking Retractor (ELR) and Automatic Locking Retractor (ALR) type

#### 1. RUNNING TEST (IN SAFE AREA)

##### for all seats:

- (a) Fasten the front seat belts.
- (b) Drive the car at 10 mph (16 km/h) and make a very hard stop.
- (c) Check that the belt is locked and cannot be extended at this time.

HINT: Conduct this test in a safe area. If the belt does not lock, remove the belt mechanism assembly and conduct the following static check. Also, whenever installing a new belt assembly, verify the proper operation before installation.



800633


#### 2. STATIC TEST

##### for all seats:

- (a) Verify that the belt locks when pulled out quickly.
- (b) Remove the locking retractor assembly.
- (c) Tilt the retractor slowly.
- (d) Verify that the belt can be pulled out at a tilt of 15 degrees or less, and cannot be pulled out at over 45 degrees of tilt. If a problem is found, replace the assembly.

##### except for driver's seat:

- (e) Pull out the whole belt, release it slightly and then pull it out again.
- (f) Verify that the belt cannot be extended further. If a problem is found, replace the assembly.



804424