

## PRECAUTION

Be careful not to grip the propeller shaft tube too tightly in the vise as this will cause deformation.

## TROUBLESHOOTING

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

	See Page						
	PR-10	PR-10	PR-10	PR-10	PR-10	PR-10	—
Parts Name	Sleeve yoke spline worn	Center bearing worn	Propeller shaft runout	Propeller shaft imbalance	Sleeve yoke stuck	Spider bearing work or stuck	Transmission extension housing rear bushing worn
Trouble							
Noise	2	1				3	
Vibration			3	4	2		1