



WINDSHIELD MOULDING COMPONENTS



N03041




B03231

WINDSHIELD MOULDING REMOVAL

LOCATION OF CLIPS AND FASTENER


- For vehicles which have black moulding, refer to diagram Type I.
- For vehicles which have metallic moulding, refer to diagram Type II.
- However, if all clips and fasteners are replaced, either diagram Type I or Type II may be referred to.

Type I (Black Moulding)



B03229 B03229

Type II (Metallic Moulding)



Z06423

Type I Applicable Models


Frame No.	Vehicle Code
0000001 ~ 1999999	VZN100, VZN105
0000001 ~ 4999999	RN80, RN85, RN90, VZN80, VZN85, VZN90,
0000001 ~ 5999999	RN110
0000001 ~ 6999999	RN101, RN106
0000001 ~ 9999999	VZN95
6000000 ~ 9999999	VNZ100, VNZ105

1. REMOVE WIPER ARMS
2. REMOVE COWL LOUVER AND WEATHERSTRIP
3. REMOVE LOWER MOULDING WITH LOWER JOINT COVERS

- (a) Remove 5 screws from the clips.
- (b) Pry up a scraper to loosen the clips from the body.
HINT: Tape the scraper tip before use.
- (c) Remove the moulding with lower joint covers and clips.


4. REMOVE SIDE MOULDING WITH UPPER JOINT COVERS

- (a) Insert the tip of a scraper between the body and moulding.
HINT: Tape the scraper tip before use.
- (b) Pry up the scraper to loosen the moulding from the claws of the clips and fasteners.
- (c) Remove the moulding with upper joint covers.


**5. REMOVE UPPER MOULDING**




- (a) Using a knife, cut off the upper moulding, as shown.
- (b) Cut off the old adhesive around the upper moulding installation area.

NOTICE: Do not damage the body and glass.

**FASTENER REPLACEMENT****REPLACE FASTENER**

- (a) Remove the damaged fastener.
- (b) Cut off the old adhesive around the fastener installation area.
NOTICE: Be carefully not to damage the body.
- (c) Clean the installation area.
- (d) Install new fastener onto the body.





WINDSHIELD MOULDING INSTALLATION

1. INSTALL CLIP INTO MOULDING

(See page [BO-19](#))

Install the clip to the appropriate place on the moulding.

2. APPLY ADHESIVE AT CLIP INSTALLATION AREA

(a) Cut out the old adhesive around the clip installation area.

NOTICE: Do not damage the body and fastener.

(b) Apply adhesive at the clip installation area so water does not collect there.

3. APPLY ADHESIVE AT UPPER MOULDING INSTALLATION AREA

4. INSTALL NEW UPPER MOULDING

Place the moulding onto the body and tap it by hand.

5. INSTALL SIDE MOULDING WITH UPPER JOINT COVERS

(a) Place the moulding with upper joint covers onto the body.

(b) Tap the moulding by hand to install it.

(c) Pry up the clips on the body side, and install them to the moulding.

6. INSTALL LOWER MOULDING WITH LOWER JOINT COVERS

(a) Place the moulding with lower joint covers onto the body.

(b) Align the clip of the moulding with the body holes, and push the moulding on the body.

7. INSTALL COWL LOUVER AND WEATHERSTRIP

(See page [BO-19](#))

8. INSTALL WIPER ARMS

(See page [BO-19](#))