

RF1A TRANSFER

DESCRIPTION

The Transfer transmits the drive force from the transmission to the front wheels, switching between 2WD, 4WD (High) and 4WD (Low).
The specifications and cross-section diagrams are as shown.



E9702

Transfer		RF1A Type Transfer
Items		
Type of Engine		22R-E
Type of Transmission		W56
Type of Reduction Gear		Counter Gear
Gear Ratio	H2 and H4	1.000
	L4	2.276
Oil Capacity liters (US qts., Imp. qts.)		1.6 (1.7, 1.4)
Oil Grade		API GL-4 or GL-5
Oil Viscosity		SAE 75W-90