


## IDLE UP SPEED

### IDLE UP SPEED INSPECTION

1. **WARM UP ENGINE**
2. **SET VEHICLE IN FOLLOWING CONDITION**
  - Blower switch high position
  - A/C switch on
  - Magnetic clutch on
3. **INSPECT IDLE UP SPEED**

**Standard:**

**950 ± 50 RPM**



### IDLE UP SPEED ADJUSTMENT

#### ADJUST IDLE UP SPEED

Adjust idle up speed with the idle adjusting screw of the VSV.