





## PREPARATION

### SST (SPECIAL SERVICE TOOLS)

	09608-30012 Front Hub & Drive Pinion Bearing Tool Set	Front axle hub bearing race Oil seal installation
	(09608-04020) Handle	
	(09608-04060) Front Hub Outer Bearing Cup Replacer	Outside race
	(09608-04100) Drive Pinion Front Bearing Cup Replacer	Inside race, Oil seal
	09628-62011 Ball Joint Puller	Steering knuckle disconnection

### EQUIPMENT

Dial indicator	
Torque wrench	
Spring tension gauge	