






















# PREPARATION

## SST (SPECIAL SERVICE TOOLS)

	09213-31021 Crankshaft Pulley Puller	Gear spline piece No. 5
	09213-36020 Timing Gear Remover	Output shaft sleeve (4WD)
	09309-35010 Transmission Rear Bearing Replacer	(2WD)
	09316-60010 Transmission & Transfer Bearing Replacer	
	(09316-00010) Replacer Pipe	
	(09316-00030) Replacer "B"	
	(09316-00070) Replacer "F"	
	09325-12010 Transmission Oil Plug	(4WD)
	09325-40010 Transmission Oil Plug	(2WD)
	09506-35010 Differential Drive Pinion Rear Bearing Replacer	Input shaft bearing
	09608-12010 Front Hub & Drive Pinion Bearing Replacer Set	Counter rear bearing
	(09608-00020) Remover & Replacer Handle	
	(09608-00050) Drive Pinion Front Bearing Cup Replacer	

	09608-35014 Axle Hub & Drive Pinion Bearing Tool Set	Front bearing retainer oil seal
	(09608-06020) Handle	
	(09608-06090) Front Hub Outer & Steering Worm Bearing Replacer	
	09950-00020 Bearing Remover	
	09950-20017 Universal Puller	

## RECOMMENDED TOOLS

	09031-00030 Pin Punch	
	09042-00020 Torx Socket T40	
	09905-00012 Snap Ring No. 1 Expander	

## EQUIPMENT

Calipers	
Dial indicator	
Micrometer	
Torque wrench	
Feeler gauge	

## LUBRICANT

Item	Capacity	Classification
Manual transmission oil	3.0 liters (3.2 US qts, 2.6 Imp.qts)	API GL-4 SAE 75W-90

## SSM (SPECIAL SERVICE MATERIALS)

08826-00090, Seal Packing 1281, THREE BOND 1281 or equivalent	Intermediate plate x Transmission Case Front bearing retainer x Transmission case
08833-00080 Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Straight screw plug Shift lever housing set bolt Front bearing retainer set bolt